

# Fashionline

## ROLLER BLINDS



### ROLLER BLINDS

- Do not pull on the fabric to operate the blind – use the cord ring-pull or rod.
- Never unroll the total fabric length from the roller.
- Do not let the blind “fly up”, as this can damage the blind and upset the tension of the roller spring.
- It is essential to have the spring tension correct – it should be sufficient to raise the blind to the top. If the blind rolls over the top then it has too much tension and this may damage both the spring and the fabric.
- If the blind will not raise when operated normally it will need to be retensioned. To retension - pull the blind right down. Remove the blind from its mounting brackets and fully roll the blind onto the roller. Replace the blind in brackets and pull down 6 turns of the roller – approx. 750mm. Remove the blind once more from the brackets and fully roll the blind on the roller. The blind should now be tensioned correctly. Large blinds may need a little more tension.
- If increased tension is required, pull the blind down 2 turns of the roller – approx. 250mm – remove it from the brackets and roll up by hand again. Replace in brackets. Repeat this step until the correct tension is obtained.
- To decrease tension, remove the blind from the brackets and unroll fabric 2 turns from the roller, then replace the blind in brackets.
- Loss of tension may occur within a “settling in” period of 10 days after your new blinds have been installed and in this event, retention the blind as outlined above.
- Note: Side winder control blinds DO NOT need tensioning.
- DO NOT oil any parts.
- Before cleaning any blind test an area in an inconspicuous place for colourfastness.
- Use a feather duster regularly. Stains or smudges may be removed using a neutral soap on a sponge. The sponge should be squeezed almost dry. Small marks can be removed by a light rub with art-gum rubber.

### GUARANTEE

Congratulations on the purchase of your Fashionline Products. Fashionline guarantee the superior quality of our Fashionline Product range. Please note this warranty does not cover commercial products and installations.

### 5 YEAR GUARANTEE

Fashionline guarantees that your Quality Fashionline Product will be free from defects in componentry for a period of five years from the date of purchase. Fabric is for a period of twelve months from date of purchase. A service call fee is applicable after twelve months. Alternatively customers can return their products to the factory for evaluation.

Under this Guarantee, the Fashionline manufacturer indicated below shall not be liable or responsible for incidental or consequential damages or for any other direct or indirect damage, loss, cost, expense or fee.

The benefits conferred by this Guarantee are in addition to all other rights and services which the purchaser has under the Trade Practices Act 1974 and similar state and territory laws.

All warranties are conditional. For the warranty to be valid customers must adhere to the care information provided with all Fashionline products. The warranty does not cover variances in colours and textures from batch to batch.

Nothing contained in the Guarantee shall be read or applied so as to purport to exclude, restrict or modify or have the effect of excluding, restricting or modifying the application in relation to the supply of any goods or services pursuant to this agreement of all or any of the Provisions of Part V of the Trade Practices Act 1974 or any relevant State Act or Territorial Ordinance which by law cannot be excluded, restricted or modified. Wholesale warranty may vary. Refer to your supplier.

### SAFETY WARNING

Keep all cords out of the reach of children. Loop or single hanging cords are a danger to children.



**IMAGE**  
**BLINDS**

[www.imageblinds.com.au](http://www.imageblinds.com.au)

**3865 1002**  
**SERVICING ALL AREAS**

HEAD OFFICE:  
97 Delta Street, Geebung

Email: [enquire@imageblinds.com.au](mailto:enquire@imageblinds.com.au)